

ADDENDUM

Universal Notebook Power Pack

Cat. No. 23-2901

Please note the following information about your power pack:

Caution: If the power indicator turns off while the power pack is in use, the output current is beyond the acceptable range, and the overload/short circuit protection activates.

Follow these steps if the power indicator turns off while the power pack is in use.

1. Disconnect the power pack from AC power, then unplug the power pack from the device.
2. Reconnect the power pack to the AC power.
3. *If the indicator is on*, reconnect the power pack to your device.

If the indicator still fails to light, take the power pack to your local RadioShack store for assistance.

© 2001 RadioShack Corporation.
All Rights Reserved.

RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

RadioShack Corporation
Fort Worth, Texas 76102

01A01

Printed in China